

IMPORTANT INFORMATION & GUIDELINES

1. It is recommended to use only 'Duracell' batteries.
2. The estimated life of the AA alkaline Duracell batteries (4 Nos.) will be approx. 10-12 months (100 operations per day).
3. The batteries should be removed from the battery compartment if the soap dispenser is not in use for a long time.
4. The LED lamp provided on the Soap Dispenser will glow only when the soap is discharged.

TROUBLE SHOOTING

SR. NO.	PROBLEM	REASON	ACTION
1.	Soap Dispenser is not working.	Battery is not installed in the battery box.	Check the battery box and install Duracell alkaline AA size batteries 4 Nos. in it.
2.	Battery is inserted but soap dispenser is still not working.	1. Batteries are not properly inserted 2. Batteries are old.	1. Take out the batteries and fix them properly as per polarity. 2. Replace the Batteries.
3.	No liquid soap comes out from the outlet	The outlet of the Soap Dispenser is blocked due to some foreign particles.	Remove the liquid soap and clear the outlet port. Refill the soap.

USER GUIDE



Excellence on Tap



SOAP DISPENSER

CAT NO. 11008



Brand Owned by
Khanja Industries

REGD. USER

CRYSTAL SANITARY FITTINGS PVT. LTD.

An ISO 9001 : 2008 Certified Company

CORR. OFF : 72, INDUSTRIAL AREA, PHASE-I, PANCHKULA -134113 (HARYANA) INDIA

PHONE : 0172-4378800-810 FAX : 0172-2573174 CUSTOMER CARE : 0172-4378821 COMMERCIAL ENQUIRY : 0172-4378822



E-MAIL : info@crystalfaucets.com WEBSITE : www.crystalfaucets.com, www.crystalbathfittings.com, www.crystalsanitaryfittings.in

Like us on www.facebook.com, crystalsanitaryfittings

ABOUT SOAP DISPENSER

Automatic soap dispensers dispense a controlled amount of soap solution or a liquid similar to a hand sanitizer. Their function is to conserve the amount of soap used and also to prevent the transmission of infectious diseases. These can also be termed as touch less or no-touch soap dispensers and can be used both in home and public restrooms; often in conjunction with automatic faucets especially in commercial washrooms.

How it works:

When user's hands are placed in the proximity of the sensor, the infrared energy triggers the pump in the dispenser to activate and dispense a designated amount of soap solution.

SPECIFICATIONS

Specifications	Cat No. 11008
Type	DC Only
Input Voltage	6 V DC
Battery	4 x AA Size Alkaline (Duracell)
Capacity	700 ml
Body Material	ABS
Sensor	Infrared
Soap	Liquid Soap
Size	155 x 130 x 130 mm

COMPOSITION

Sr. No.	Particulars
1	Soap Dispenser with Wall Clamp
2	AA Size Duracell Batteries (4 Nos.)
3	Screw and Plastic Plug (2 Nos.)
4	Top cover locking key
5	User Guide
6	Battery Compartment Locking Screw

INSTALLATION PROCEDURE

1. Mark holes to fix the clamp on the wall and drill with the help of a drilling machine.
2. Fix the wall clamp with the help of screws provided.
3. Open the battery cover and insert AA Size Alkaline Duracell batteries (4 Nos.) in the battery compartment with polarity as indicated.
4. Hang the dispenser body on the wall clamp.
5. Open the top cover to fill liquid soap in it.
6. Lock the top cover with the help of key provided and switch 'ON' with the help of the ON/OFF Button.
7. The Soap Dispenser is now ready to work.

DIAGRAM OF SOAP DISPENSER

